

Release notes

Wellnomics® Sit Stand

Version 1.6.2

Product	Wellnomics® Sit Stand
Release version	1.6.2
Date of release	February 2019
Support information	For more information or support, please visit our website www.wellnomics.com or email us at support@wellnomics.com .

Contents

Installing and Upgrading.....	3
New Features and Enhancements.....	4
Version 1.6.2 Feb 2019.....	4
Bug Fixes.....	5
Version 1.6.2 Feb 2019.....	5

Installing and Upgrading

Installation

For a new installation on a stand-alone PC, double-click on the product installer executable to launch the installation application. Further instructions are given during the installation process. If you have a cable to connect your sit-stand desk to your computer make sure to plug this in before you run the installer.

Upgrades

This version of the product will automatically detect and upgrade any existing installation preserving your settings.

Minimum System Requirements

- PC with 1 gigahertz or higher processor 32-bit or 64-bit processor
- 1 GB RAM
- 180 MB of available hard disk space
- 1024 x 768 or higher-resolution video adapter and monitor
- Windows 10, Windows 8/8.1, Windows 7

Actual system requirements may vary based on individual PC configurations, taking into account resources used by other applications that may already be installed.

New Features and Enhancements

Version 1.6.2

Feb 2019

Supports https

Now supports https communication for all data sync to the server. Uses secure internet protocol TLS 1.2 by default. (WSS-777)

New registration keys

Now supports new Wellnomics Registration keys. Old keys will be gradually phased out and will not be supported in later versions. Customers with an old key may need to contact Wellnomics for a replacement registration key if their old key does not work in the new version. (WSS-710)

Updated Dutch translation

Dutch translation has been updated and improved. (WSS-769)

Bug Fixes

Version 1.6.2

Feb 2019

Error in trial expiry fixed

Trial period was not displayed correctly and after trial expiry message said "Invalid license" instead of "Trial expiry" which could be confusing to the user. Fixed in latest version. (WSS-773)

Desk movement arrow pointing wrong direction in some situations

When using in standalone mode (not connected to the desk) the Arrow direction was sometimes pointing in the wrong direction when the user chooses "Adjust workstation". This has been fixed now (WSS-568)

--- END ---